


Exploded view Forester V.2015.05.11



Ref.	Article nr.	Description	Ref.	Article nr.	Description
1	KSI027438	blade 380-7.5	16A	KZSI27302	cramp housing (S) assembly
2	KZSI2730041	blade cover	16B	KZSI27303	cramp housing (L) assembly
3A	KZSI27301	plastic insert	17	KZSI2730402	rubber sleeve
3B	KZSI2730032	clip	18	KZSI2730403	rubber sole
4	KSI327003N	blade fixing pipe	19	KZSI2730401	rubber grip tape
5-6-7	KSI310540	boltset	20A	KZSI2730022	upper pole Forester 3000
8	KZSI2720432	bolt(2 required)		KZSI2730026	upper pole Forester 4500
9	KZSI2720405	spring push button	20B	KZSI2730023	middle pole Forester 3000
10	KZSI3650438	push button		KZSI2730027	middle pole Forester 4500
11	KZSI3700477	spring fixing bolt	20C	KZSI2730012	lower pole Forester 3000
12-13-14-15		see assembly 16A or 16B		KZSI2730014	lower pole Forester 4500