

GARDENA Accu Rasenmäher PowerMax Li-40/32 Art.-Nr. 5033




Bild Nr. Picture No.	Ersatzteil-Nr. Spare Part No.	Bezeichnung	Description	Désignation
Art. 5033		Accu-Rasenmäher PowerMax Li 40/32	Accu Rechargeable Lawnmower PowerMax Li 40/32	Tondeuse sur accu PowerMax Li 40/32
1	9845-00.701.00	Ladegerät	Battery charger	Transformateur de charge
2	9842-00.701.00	Wechsel-Akku BLi-40/100 (9842-20)	Replacem.Battery BLi-40/100 (9842)	Batterie remplaçable BLi-40/100 (9842)
2	9843-00.701.00	Wechselaccu BLi-40/160 (9843-20)	Replacem.Battery BLi-40/160 (9843)	Batterie remplaçable BLi-40/160 (9843)
3	5032-00.600.15	Zunge	Slide lock	Disque d'arrêt
4	5032-00.600.14	Fangkorb	Grass catcher	Sac de ramassage
5	5032-00.600.13	Heckklappe	Safety flap	Hayon
6,7	5032-00.650.00	Korbdeckel	Basket cover	Couvercle de panier
8	5032-00.650.03	Tragegriff	Carrying handle	Poignée de transport
9	5032-00.630.03	Hebel	Trigger	Gâchette
10	5033-00.630.01	Abdeckung	Cover	Couvercle
11	5032-00.630.02	Abdeckung Griff, unten	Lower cover handle	Couvercle poignée, inférieure
12,29	5032-00.600.67	Schraube ST4x16 T20	Screw ST4x16 T20	Vis ST4x16 T20
13	5032-00.630.50	Schalter	Switch	Interrupteur
14	5032-00.630.04	Abdeckung Griff, oben	Upper cover handle	Couvercle poignée, supérieure
15	5032-00.630.53	Feder	Spring	Ressort
16	5032-00.630.05	Knopf	Button	Bouton
17	5033-00.630.02	Abdeckung	Cover	Couvercle
18	5033-00.631.00	Kabel	Wire	Câble
20	5032-00.600.71	Scheibe	Washer	Disque
21	5032-00.670.00	Flügelmutter	Wing nut	Écrou à oreilles
22,23	5032-00.902.00	Holm Unterteil	Lower handle bar	Guidon partie inférieure
24	5032-00.600.66	Bolzen	Bolt	Boulon
3,8,20,21,24,25,63	5033-00.901.00	Polybeutel	Accessory bag	Sachet d'accessoires
25	5032-00.600.17	Kabelführung	Cable clip	Guide-câble
26	5032-00.660.00	Flügelmutter	Wing nut	Écrou à oreilles
27	5032-00.600.68	Mutter	Nut	Ecrou
28	5032-00.600.52	Scheibe	Washer	Disque
30	5032-00.600.64	Feder	Spring	Ressort
31	5032-00.600.12	Kabelklemme	Cable clip	Serre-câble
34	5032-00.600.09	Lagerbuchse	Pivot pin	Coussinet
35	5032-00.600.05	Hinterrad	Rear wheel	Roue arrière
36	5034-00.600.54	Scheibe Starlock	Washer Starlock	Disque Starlock
37	5034-00.600.03	Radkappe hinten	Wheel cover, back	Enjoliveur de roue arrière
38	5032-00.600.11	Drücker Höhenverstellung	Knob Height Adjust	Bouton réglage d'hauteur
39	5032-00.600.02	Gehäusestrebe	Housing rod	Renforcement de carter
40	5032-00.600.60	Filter	Filter	Filtre
41	5032-00.600.04	Vorderrad	Front wheel	Roue avant
43	5034-00.600.02	Radkappe vorne	Wheel cover, front	Enjoliveur de roue avant
45	5032-00.600.59	Torsionsfeder	Torsion spring	Ressort à torsion
46	5032-00.620.00	Höhenverstellung kpl.	Arm height adjust cpl.	Réglage d'hauteur, cpl.
47	5032-00.600.58	Torsionsfeder	Torsion spring	Ressort à torsion
48	5032-00.600.07	Zahnrad	Gear wheel	Pignon
49	5032-00.600.69	Stopfen	Plug	Bouchon de fermeture
50	5032-00.600.56	Messerbolzen	Blade bolt	Boulon de lame
51	5032-00.600.70	Scheibe	Washer	Disque
52	4100-00.701.00	Ersatzmesser (Art. 4100-20)	Blade (Art. 4100-20)	Lame (Réf. 4100-20)
53	5033-00.600.01	Lüfter	Ventilator	Ventilateur
55	5033-00.640.52	Feder	Spring	Ressort
56	5033-00.600.51	Bolzen	Bolt	Boulon
57	5033-00.610.00	Motor	Motor	Moteur
59	5033-00.620.00	Elektronik	Electronic circuit	Électronique
60	5033-00.642.00	Verkabelung	Wiring	Cablage
62	5033-00.641.53	Sicherheitsschalter	Safety switch	Interrupteur de sécurité
63	5033-00.600.18	Knopf	Knob	Bouton
64	5033-00.640.02	Kontaktstecker	Contact plug	Fiche de contact
66	5032-00.640.50	Filter	Filter	Filtre
69	5033-00.640.01	Abdeckung vorne	Front cover	Couvercle avant
71	5033-00.640.04	Abdeckung	Cover	Couvercle
		Nur die aufgeführten Teile sind lieferbar!	Only the mentioned spare parts are available!	Seules les pièces indiquées sont disponibles!